PDA Training Course Extractables & Leachables 25-26 April 2024

THE MECHANISM OF POLYMER MIGRATION A DESCRIPTIVE APPROACH

Dr. Piet Christiaens









OVERVIEW

- 1. Fabes model a descriptive approach
- 2. Factors affecting leaching
 - Solubility of a leachable in a polymer
 - Diffusion of a leachable in a polymer
- 3. Application specific effect
 - Supersaturation
 - Outgassing
 - Blooming





OVERVIEW

- 1. Fabes model a descriptive approach
- 2. Factors affecting leaching
 - Solubility of a leachable in a polymer
 - Diffusion of a leachable in a polymer
- 3. Application specific effect
 - Supersaturation
 - Outgassing
 - Blooming





1. FABES model – a descriptive approach

Migration of leachables from polymers into a liquid can be described by

THE FABES MODEL:

$$\frac{m_{L,t}}{A} = 0.1c_{P,0}\rho_P d_P \left(\frac{\alpha}{\alpha+1}\right) \left[1 - \sum_{n=1}^{\infty} \frac{2\alpha(1+\alpha)}{1+\alpha+\alpha^2 q_n^2} \exp\left(-\frac{Q_P}{d_P^2} t \frac{q_n^2}{d_P^2}\right)\right]$$

$$D_P = 10^4 \exp[A_P - 0.1351(MW)^{2/3} + 0.003MW - 10450/T]$$

Important factors:

C_{n o}: initial migrant concentration i/t polymer MW: molecular weight of the migrant (Da)

 ρ_p : density of the polymer (g/cm³) V_L : volume of the liquid (cm³) d_p : thickness of the polymer (cm) V_p : volume of the polymer (cm³)

D: diffusion coefficient (cm²/s) T: temperature (K)

 A_p : "mobility" of the polymer $K_{P,L}$: partition coefficient $\left(=\frac{C_{L,t=\infty}}{C_{P,t=\infty}}\right)$

→ Very complex model: more qualitative discussion of factors in next slides





OVERVIEW

- 1. Fabes model a descriptive approach
- 2. Factors affecting leaching
 - Solubility of a leachable in a polymer
 - Diffusion of a leachable through the polymer
- 3. Application specific effect
 - Supersaturation
 - Outgassing
 - Blooming





2. FACTORS AFFECTING LEACHING

Leaching will depend upon:

SOLUBILITY of a leachable *IN* the polymer



- Polymer morphology
 Temperature
 Age/sterilization

 - Structure and molecular weight of a leachable

DIFFUSION of a leachable *THROUGH* the polymer



- Polymer morphology

- 2. Temperature 3. Polymer type (T_g) 4. Molecular weight of a leachable
- Contact fluid/environment






2.1 SOLUBILITY OF A LEACHABLE IN A POLYMER

1. Polymer morphology


Amorphous



Polymer additive/impurity

- » Dissolves in amorphous phase
- » Insoluble in crystalline phase

Semi-crystalline



PC, PVC, PS, PU

CRYSTALLINE SITES:
BARRIER FOR
MIGRATION

PE, PP, PET, EVA, PEEK, PA






2.1 SOLUBILITY OF A LEACHABLE IN A POLYMER

2. Temperature

As temperature increases, solubility increases






Scissions



2.1 SOLUBILITY OF A LEACHABLE IN A POLYMER

3. Ageing / sterilization

- oPolymer degradation
- oChanges in polymer crystalinity
- \circ Polymer additive degradation $_{\gamma\text{-ray}}$



This will impact the: **LEACHABLES SOLUBILITY LEACHABLES MIGRATION**

CONCLUSION:

» PERFORM E&L TESTING ON FINAL (STERILIZED) SYSTEMS







2.1 SOLUBILITY OF A LEACHABLE IN A POLYMER

4. Structure and molecular weight of a leachable


Molecular weight → larger molecules = lower solubility



VS.



Irganox 1010 (MW 1178)



- II. Polarity "match" →
- → structurally ALIKE
- III. Melting point
- \rightarrow higher T_{melt} = lower solubility
- → impacted by molecular symmetry & crystallinity





2. FACTORS AFFECTING LEACHING

Leaching will depend upon:


SOLUBILITY of a leachable **IN** the polymer

DIFFUSION of a leachable **THROUGH** the polymer





FICK'S 2nd LAW OF DIFFUSION:



$$\frac{dC}{dt} = O \frac{d^2C}{dx^2}$$

Concentration gradient

with

C: concentration

t: time $(t_A \rightarrow t_B)$

x: distance $(x_A \rightarrow x_B)$

D: Diffusion coefficient \rightarrow measure for "mobility"

$$\Rightarrow D = D_0 e^{-\frac{E_A}{RT}}$$






1. Polymer morphology

Crystalline sites:
 Impermeable barrier
 for polymer additives



More barrier for diffusion in:
 Semi-crystalline polymers







2. Temperature


Remember:

$$D = D_0 e^{-\frac{E_A}{RT}}$$

 $(E_A$: activation energy, R: gas constant, T: temperature, D_0 the maximal diffusion coefficient (at infinite T))

Therefore:

If $T \uparrow$, then $D \uparrow$



DIFFUSION of impurities/polymer additives will **increase exponentially** when **temperature increases**






3. Polymer type

I. Glass Transition Temperature (T_a)

Polymer transitions from **GLASSY** $(T < T_g)$ to **RUBBERY** $(T > T_g)$

EXAMPLES


$$\begin{array}{lll} \mathsf{LDPE} & T_g = -125\,^\circ C \\ \mathsf{POM} & T_g = -50\,^\circ C \\ \mathsf{PP} & T_g = -25\,^\circ C \\ \mathsf{PBT} & T_g = 70\,^\circ C \\ \mathsf{PVC} & T_g = 81\,^\circ C \\ \mathsf{ABS} & T_g = 110\,^\circ C \\ \mathsf{PC} & T_g = 150\,^\circ C \end{array}$$





3. Polymer type


Lower T_g = higher potential for diffusion at room temperatures







3. Polymer type (FRACTIONAL) FREE VOLUME



Ratio of: Interstitial space (between polymer chains)

Total volume of the polymer

Polymers in a **Rubber State** ($T_q < T$) typically have **HIGHER** free volume


More <u>free volume</u> promotes diffusion





4. Molecular weight of leachable

Diffusion increases with decrease in M.W.








4. Molecular weight of leachable

Oligomeric additives -> reducing diffusion




BHT: M.W. 220

Irganox 1076: M.W. 530

Irgafos168: M.W. 646

Irganox 1010: M.W. 1176



Additive DEGRADATION into smaller molecules → FASTER DIFFUSION of degradants Example:

3,5-Di-*tert*-butyl-4-hydroxyphenyl propionic acid methyl ester


Degradation product of Irganox 1010 /Irganox 1076





5. Contact fluid / environment


Two Important aspects:







- 5. Contact fluid/environment
- 1. Solubility of the leachable in the contact fluid



In general for most organic compounds:

Organic / hydrophobic contact solutions = HIGH SOLUBILITY solvents
WFI/hydrophilic contact solutions = LOW SOLUBILITY solvents






5. Contact fluid/environment

Interaction of the contact fluid with the polymer

Solvent can "plasticize" or "swell" a polymer **SOLVATED LAYER**



ENHANCED DIFFUSION OF LEACHABLES



ACCELERATED LOSS





OVERVIEW

- 1. Fabes model a descriptive approach
- 2. Factors affecting leaching
 - Solubility of a leachable in a polymer
 - Diffusion of a leachable in a polymer

3. Application specific effect

- Supersaturation
- Outgassing
- Blooming





3. APPLICATION SPECIFIC EFFECTS

1. Super saturation

LIQUID FILM is formed via

- Evaporation during storage
- Transportation

Film may be different in composition than the DP

Diffusion of rubber compounds into small volume

- Metals
- o Organic


Can cause aggregation, particle formation

May be irreversible

 Particles do not dissolve anymore when in contact with the total DP volume

LIQUID FILM may also act as "barrier"

- for migration
- for outgassing (see next slide)








3. APPLICATION SPECIFIC EFFECTS

2. Outgassing



No "Liquid Film" barrier on rubber (see previous slide)

Material (e.g.):
Film (Overwrap)

Rubber
(Lyo Vial,
Needle Shield)

Solvent: air, gas
phase

Outgassing is mainly an issue for:

- Volatile organic compounds
- Semi-volatile organic compounds





3. APPLICATION SPECIFIC EFFECTS

3. Blooming

What is it?

- Blooming is a physical phenomenon
- Observed in polymers which are (super)saturated with additives
- A process of diffusion controlled migration of additives from the polymer
- Typical for additives with low solubility & high diffusion rate

Typical conditions when blooming occurs

- Low solubility of the additive in the polymer
- High diffusion of the additive through the polymer
- Dosing of the additive into the polymer close to the solubility of the additive in polymer
- Low temperature applications may accelerate blooming process (lower solubility, but also lower diffusion...)







